BOSCH

English

Dishwasher Use & Care Manual for SHU 3030 Series



Quick Reference Index

IMPORTANT SAFETY INSTRUCTIONS	2
GROUNDING INSTRUCTIONS	2
ABOUT YOUR DISHWASHER	3
GETTING TO KNOW YOUR DISHWASHER	3
BEFORE USING FOR THE FIRST TIME	4
GETTING STARTED	4
PREPARATIONS FOR WASHING	4
SPECIAL INSTRUCTION, TABLE 1	5
LOADING	
LOADING THE TOP RACK	6
LOADING THE LOWER RACK	6
USING THE DISPENSERS	
DETERGENT USE	7
DETERGENT DISPENSER	7-8
RINSE AGENT INDICATOR	7
RINSE AGENT DISPENSER	8
RINSE AGENT REGULATOR	8
CYCLE SELECTION	8
CYCLE SELECTION CHART	9
OPERATION	10
TO INTERRUPT OR RESET PROGRAM	10
UNLOADING	10
CARE & CLEANING	10-11
SERVICE and REPAIR	12
SELF-HELP	13
WARRANTY	14

READ THIS MANUAL

for important safety and operating instructions

English

IMPORTANT SAFETY INSTRUCTIONS

WARNING — When using your dishwasher, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Bosch dishwashers are provided with two manuals: an Installation Instruction Manual and a Use and Care Manual. Read all instructions before using the dishwasher.
2. Use the dishwasher only for its intended function.
3. Use only detergents or wetting agents recommended for use in a dishwasher and keep them out of the reach of children.
4. When loading items to be washed:
   a. Locate sharp items so that they are not likely to damage the door seal; and
   b. Load sharp knives with the handle up to reduce the risk of cut-type injuries.
5. Do not wash plastic items unless marked "dishwasher safe" or the equivalent. For plastic items not so marked, check the manufacturer's recommendations.
6. Do not touch the heating element during or immediately after use.
7. Do not operate your dishwasher unless all the enclosure panels are properly in place.
8. Do not tamper with controls.
9. Do not abuse, sit on, or stand on the door or dish rack of the dishwasher.
10. To reduce the risk of injury, do not allow children to play in or on the dishwasher.
11. Under certain conditions, hydrogen gas may be produced in a hot water system that has not been used for two weeks or more. Hydrogen gas is explosive. If the hot water system has not been used for such a period, before using the dishwasher turn on all hot water faucets and let the water flow from each for several minutes. This will release any accumulated hydrogen gas. As the gas is flammable, do not smoke or use an open flame during this time.
12. Remove the door to the washing compartment when removing an old dishwasher from service or discarding.

WARNING — This dishwasher must be grounded in accordance with the National Electrical Code and/or local codes. These must be carefully followed in all cases. See Installation Instructions provided with this dishwasher for complete installation information. Make sure this dishwasher has been properly grounded and installed by a qualified installer before using.

SAVE THESE INSTRUCTIONS

GROUNDING INSTRUCTIONS

This appliance must be connected to a grounded metal, permanent wiring system; or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the dishwasher.

HOUSEHOLD USE ONLY

ABOUT YOUR DISHWASHER

Congratulations on having selected a BOSCH dishwasher, the choice of those that demand quiet and exceptional cleaning performance from their dishwasher. The Bosch SHU 3030 series dishwashers offer the following standard features:

- Stainless steel inner liner and inner door
- Exceptionally low water consumption
- Four spraying levels
- Flow-Through Heater™ for temperature boosting
- Triple filter system

GETTING TO KNOW YOUR DISHWASHER

Figure 1, below, is an illustration of the dishwasher with its features called out. For an explanation of the feature turn to the page indicated.

English



Figure 1.

English

BEFORE USING FOR THE FIRST TIME

Before beginning to use your dishwasher for the first time:

1. Check to make sure that the voltage on which the dishwasher is to operate is the same as shown on the rating plate.
2. Check to make sure that the water valve to the dishwasher is open. The installer may have closed the valve upon completing the installation.



SHU 3030 Series Control Panel

Figure 2.

GETTING STARTED

The operation of your Bosch dishwasher is summarized below:

1. Load the dishwasher.
   Refer to Table 1 for items suitable for washing in the dishwasher. The dishwasher should be loaded with pots, pans, dishes and silverware according to the instructions provided under the following section titled **LOADING.**
2. Add detergent and check rinse agent.
   Detergent must be placed in the detergent dispenser compartment as described in the following section titled **DETERGENT USE.** The use of a rinse agent is required to ensure good cleaning and drying result. See section titled **RINSE AGENT DISPENSER.**
3. Check motion of wash arms.
   The wash arms must be free to move and should not be blocked by any item extending so far above lower rack as to block upper arm or by any items hanging below either the upper or lower rack to obstruct the motion of the wash arms. See following section titled **OPERATION**.
4. Close the door of the dishwasher.
   Make sure that the door is completely closed and latched.
5. Select a wash cycle, see Table 2.
6. Start the dishwasher.
   Turn the "Start and Run Knob" to the cycle you desire **(Power Scrub or Regular Wash)**. Then choose the temperature option you want for the cycle you chose by depressing the "High Temp. Wash" or the "Regular Temp. Wash" buttons. If you choose the "**Rinse and Hold**" Cycle on the "Start and Run Knob", then you also need to choose the Rinse & Hold" button. After you are finished selecting your cycle and temperature, then depress the On/Off button. The indicator light above the On/Off button will become illuminated and the dishwasher will start. The "Start and Run Knob" will rotate clockwise as the dishwasher cycle progresses. It is possible to discern at what stage the cycle is in, by noting the position of the knob indicator.
7. To stop dishwasher.
   Depress the On/Off button. The indicator light above the On/Off button will turn off. See the following section titled **TO INTERRUPT OR RESET CYCLE.**

PREPARATIONS FOR WASHING

Very little preparation is required before placing dishes, pots, pans, etc. into the dishwasher. However, some preparation is required:

- Large solids, such as, bones, large seeds, shells, skins, leafy vegetables, meat trimmings, etc. should be removed either by scraping into a wastebasket, or into your food disposer.
- Large amounts of any type of leftover food should also be scraped into a wastebasket or into your food disposer.
- Pots and pans that have burned-on food, the food is blackened, should be pre-soaked and scoured. The dishwasher cannot remove burned-on food.
- Do not place the following items in the dishwasher:
  > toothpicks
  > small bones and bone slivers
  > paper products such as paper plates and paper napkins
  > plastic bags or plastic packaging material.

In general, try to remove food scraps and place the items to be washed in the dishwasher before the food has had a chance to dry-on. Dried-on food is more difficult to remove. If there will be an extended period of time before the dishwasher will be run it is recommended that the "Rinse & Hold" cycle be used.

Other than the above, no special preparation or pre-rinsing is required for dishes, pots and pans or utensils with normal amounts of food soil.

MATERIAL	DISHWASHER USE	COMMENTS AND/OR SPECIAL INSTRUCTIONS
ADHESIVE JOINED ITEMS	NOT RECOMMENDED	Items joined by adhesives, whether plastic, wood, bone, steel, copper or tin, etc. may be loosened.
ALUMINUM	USUALLY SAFE	Colored anodized aluminum may fade over time. Minerals in the water may cause spotting or darkening of aluminum. This can usually be removed by scouring with a soap filled steel wool pad.
BONE HANDLED UTENSILS	NOT RECOMMENDED	Handles may separate.
CHINA & STONEWARE	USUALLY SAFE	It is highly recommended however that "on-glaze" decorated china, handpainted and gold or platinum trimmed, or antique china or stoneware be hand washed. If there is any doubt, please check with the manufacturer of your set or test by washing one piece with each load for a month and comparing this piece with the rest of the set to determine if there has been any fading or discoloration.
CRYSTAL	USUALLY SAFE	Decorated crystal, those handpainted, "on-glaze", or metal trimmed, may discolor, fade, or spot. It is recommended that these be hand washed. Also, fragile glassware is highly breakable, be sure to set the pieces so that they do not topple during washing and so that they do not knock against other pieces.
GLASS	USUALLY SAFE	Milk glass may yellow.
NON-STICK COATINGS	USUALLY SAFE	After drying the non-stick coating should be covered with a light coating of vegetable oil.
IRON	NOT RECOMMENDED	Iron will rust. Wash by hand and dry immediately.
PEWTER	NOT RECOMMENDED	Pewter will tarnish. Wash by hand and dry immediately.
PLASTIC	USUALLY SAFE	Only wash "dishwasher safe" plastic items.
STAINLESS STEEL	USUALLY SAFE	Do not let stainless steel items contact copper or sterling silver or silverplate items.
STERLING SILVER & SILVERPLATE	USUALLY SAFE	Do not allow to come in contact with stainless steel or copper items.
TIN	NOT RECOMMENDED	Tin will rust. Wash by hand and dry immediately.
WOOD	NOT RECOMMENDED	Wooden bowls, wooden utensils and wood handled utensils can warp, crack or lose their finish.
NON-DISHWARE ITEMS	NOT RECOMMENDED	The Bosch dishwasher is only intended for use in cleaning standard household dishware items.

Table 1.

LOADING

English

LOADING THE TOP RACK

The top rack is designed for glasses, cups, plates, bowls and saucers. Glasses, cups, plates, bowls, saucers and small pots may be loaded in many different positions to fit your needs. Figure 3, shows a typical mixed load for an upper rack washing load.

The dishwasher should be loaded so that water can circulate freely and reach every part of every item that is to be cleaned:

- Cups, glasses and containers should be placed in upper rack upside down so that water drains off of them and does not collect in them. Tall narrow vessels, such as a vase or tall glass, should be placed in the lower rack, near the middle, for the best cleaning result.



Figure 3.

- China, crystal and other delicate items must be placed so that they do not touch each other during dishwasher operation. Chipping or other damage may occur if items can touch each other while the dishwasher is running.

- Large serving spoons and forks, spatulas, tongs and large knives can be placed in the top rack. Be sure to space these large utensils so that water may flow freely over them and so that water does not collect in them; - - - serving spoons and ladles should be placed facing downward so as not to collect water.

- At completion of loading of the upper rack check to make sure that nothing is protruding through or hanging beneath the bottom of the rack, which could block the rotation of the spray arm.



Figure 4.

LOADING THE LOWER RACK

- Large and/or heavily soiled items should be placed in the lower rack of the dishwasher. Heavily soiled pots and pans should be placed face down. See figure 4.

- Silverware should be mixed when placed in the silverware basket. The purpose of mixing the silverware is to avoid having them nest together. For example, if spoons were placed side by side in the basket, they might 'nest together'. If this happened, then the water would not properly circulate across the spoons to clean the surfaces.

- Silverware should be placed in the silverware basket with the handles down, with the exception of the knives, which in order to avoid accidentally cutting oneself, should be placed with the handles up.

If you do inadvertently load the silverware basket with the knife blades up it is recommended, to avoid cutting yourself when unloading, that you remove the silverware basket from the dishwasher and tip the contents out onto a cutting board.

USING THE DISPENSERS

For the best washing result it is important to use the correct amount of detergent and rinse agent.

DETERGENT USE

Use only fresh dishwashing detergent (powder is recommended) manufactured specifically for dishwasher use. Use of other types of detergents will result in excessive suds. Be sure to check the phosphate content of the detergent to be used. Phosphate helps prevent the minerals in hard water from forming a film or spots on dishes. Hard water requires your detergent to work harder. In hard water areas you will find that detergents with high phosphate levels will provide a better result. If the phosphate level is low, below 8.7%, you may have to use extra detergent in hard water areas.

Be sure to follow the dishwasher detergent manufacturer's instructions when using the detergents. Concentrated detergents usually call for lower usage than do standard detergents.

Note: Do not use detergent when the Rinse & Hold cycle has been selected.



Figure 5.

DETERGENT DISPENSER

The detergent dispenser on the Bosch dishwasher is located on the inside of the door, see figure 1 as well as figure 9 and 10. The detergent dispenser cover may be opened by pulling the release tab (figure 10) toward you.

Once the cover is open you will see two level marks: "25" and "15". These refer to the volume when filled level in milliliters. 15 milliliters is equivalent to 3 teaspoons. If the detergent dispenser is completely filled it can hold 45 milliliters, or roughly 9 teaspoons.



Figure 6.

The amount of detergent to be used depends on the cycle selected and the water hardness:

- For water of medium hardness and "Regular Wash" cycle it is recommended that the detergent dispenser be filled to the 25 milliliters, (5 tsp.) level.
- With hard water, or with the "Power Scrub" cycle, it is recommended that the detergent dispenser be completely filled, roughly 9 teaspoons.
- With soft water the amount of detergent may be reduced.

If you have water of medium or higher hardness and the dishes do not come out clean, the cause (in the majority of cases) is the use of too little detergent rather than too much. If you have very soft water, or chemically treated soft water, special care should be taken to use the minimum amount of detergent. For these situations a high quality, low phosphate detergent is recommended. Too much detergent combined with soft water may cause etching of glassware.

After filling the detergent compartment close the cover by sliding it over the detergent chamber and pressing down on the button until it clicks shut. The detergent will be dispensed automatically during the wash portion of the cycle.

If the cover of the detergent dispenser is closing fully but it won't latch, this is most likely due to the dishwasher having been stopped in mid cycle. Check the position of the "Start and Run Knob", see Figure 2, to see if cycle has been completed. If the cycle is not completed please refer to section of this manual titled **TO INTERRUPT OR RESET CYCLE** to reset cycle.

RINSE AGENT INDICATOR

There is level indicator on the dispenser, see Figure 11 and 13. This indicator shows the level of rinse agent that is in the rinse agent reservoir. As received, and when empty, the level indicator on the dispenser will appear blank. When the rinse agent reservoir is full the level indicator on the dispenser will appear dark.

English



Figure 7.

IMPORTANT

Rinse agent, or a rinse aid, is used to diminish water spotting and to provide optimum drying results. Rinse agent **must** be used at all times with the Bosch dishwasher.

RINSE AGENT DISPENSER

The rinse agent dispenser is located next to the detergent dispenser. See figure 12. Rinse agent is available in liquid or solid form. Do not use the solid type of rinse agent in the Bosch dishwasher.

To fill the rinse agent reservoir (refer to Figure 12):

- Open the dishwasher door fully.
- Open the cover of the rinse agent dispenser.
- Add rinse agent to the reservoir until the clear level indicator turns completely dark. The reservoir is full when the level indicator is dark.
- Close the cover of the rinse agent dispenser. Make sure that it is firmly snapped closed.



Figure 8.

RINSE AGENT DISPENSER REGULATOR

The rinse agent reservoir of the Bosch dishwasher is provided with a regulator calibrated from 1 to 6. See Figure 13. This regulator controls the amount of rinse agent dispensed. The dishwasher leaves the factory preset to 3½. This has been chosen as the average setting, however:

- if you see streaks, it is recommended that the regulator be turned to a lower number.
- if water spots appear, it is recommended that the regulator be turned to a higher number.



Figure 9.

TO ADJUST SETTING:

- Open the cover of the rinse agent dispenser.
- Turn the setting indicator to the desired setting. See Figure 13.
- Close the cover of the rinse agent dispenser. Make sure that it is firmly snapped closed.

CYCLE SELECTION

The dishwasher will wash and dry the contents based on cycle selection made. Refer to the CYCLE SELECTION CHART, Table 2. The most appropriate cycle for the load to be washed can be selected from this table by comparing the load type and the amount and condition of the food on the items to the charts recommendations.

Cycle Selection Chart for SHU 3030



Shown above are the range of values that may be obtained while running the dishwasher under normal conditions. Actual values may vary. The actual cycle duration, water and energy usage are dependent upon inlet water temperature.

Note: When you select "Rinse & Hold" on the "Start and Run Knob", you must also select "Rinse & Hold" on the "Temp. Options" button. Otherwise the water will not get hot and your dishes will be rinsed in cold water for an extended period of time and the detergent dispenser will not open.

Table 2.

OPERATION

English

Once detergent has been added and before closing the door of the dishwasher check the wash arms to ensure that they are free to move. With the detergent in the dishwasher and arms free to move:

- Close the door of the dishwasher making sure that door latch is closed.
- Depress the button for the temperature you desire.
- Turn the "Start and Run Knob" to "**Power Scrub**", "**Regular Wash**", or "**Rinse & Hold**" (depending upon the cycle you choose) and depress the On/Off button. See Figure 2. The indicator light above the On/Off button will become illuminated to indicate that the dishwasher is on and the cycle will begin.

Note: DO NOT USE DETERGENT IF YOU CHOOSE "RINSE & HOLD."

TO INTERRUPT OR RESET CYCLE

To interrupt cycle simply depress the On/Off button to stop operation. If you are interrupting the cycle during a wash or rinse cycle please wait until the water noises stop before opening the door. After opening the door leave it ajar for a few minutes. The cycle then may be resumed by closing the door and depressing the on/off button.

As a safety feature the dishwasher will automatically turn itself off whenever the door is unlatched. However, if the door is opened quickly while in a wash or rinse cycle some water may splash out of the dishwasher. For this reason it is recommended that the machine always be switched to off before opening the door.

If you wish to reset the cycle to its beginning after stopping the dishwasher:

1. Close the door of the dishwasher. Make sure that the door is completely closed and latched.
2. Turn the "Start and Run Knob" to your cycle selection.
3. The dishwasher is now reset and ready to run your selected wash cycle.

UNLOADING

When unloading the dishwasher always unload the lower rack first and then unload the upper rack. This will minimize the chance of drops from the upper rack falling on the dishes in the lower rack. The silverware basket of the Bosch dishwasher may be removed for easy unloading.

Also, when unloading, it is recommended that the dishes be allowed to cool before handling. The dishes will cool more quickly if the door is opened slightly.



Figure 10.

CARE and CLEANING

The Bosch dishwashers have a triple filter system comprised of: a microfilter, a fine filter and a coarse filter. The microfilter is self-cleaning, but the coarse filter and fine filter will sometimes be found to have collected items; from bones to toothpicks or straws that been left on the plates or in the glasses. For this reason the following maintenance should be observed:

- Filters

  The filters should be checked on a regular basis. To remove the filters, turn the knurled ring handle of the coarse/microfilter ¼ turn counter-clockwise, see Figure 10, and lift out the coarse/microfilter. After removing the coarse/microfilter the fine filter should also be inspected from time to time. Examine the filters. If large solids, such as bones, or large seed(s) are present, remove the filters and dispose of the large solids by emptying into a waste basket. If any other items have been trapped by the filters, paper labels for example, these should also be removed while you have the filters out of the dishwasher. These smaller items can usually be flushed out under running water if you have trouble removing them by hand.

  After cleaning, reinsert the filters in the dishwasher making sure to press the filters firmly into position, and then turning the knurled ring ¼ turn clockwise until locked. Pull gently on the knurled ring to make sure the filters are again locked in place.

Other areas requiring periodic maintenance are the wash arms, stainless steel tank, inner door, and door gasket:

- Wash Arms

  The wash arms should be checked on a regular basis to assure that the spray orifices are clear and unobstructed. If the wash arms require cleaning they are easily removable:



Figure 11.

> The lower wash arm simply snaps into place and can be removed by pulling upwards.

> The upper wash arm is held in position by a locking ring that can be released by turning it approximately 1/8 turn. See figure 15.

After cleaning, reattach the wash arms by reversing the action used to remove them.

- Stainless Steel Tank and Door
  The outer edges of the inside door panel should be cleaned on a regular basis to remove food particles that can gather there from normal loading. If spots begin to appear on the stainless steel door or tank, check to make sure that the RINSE AGENT RESERVOIR has rinse agent in it. It is also possible that the wash arms are blocked, which prevented the door as well as your dishware from being properly washed and rinsed. Check the wash arms to make sure they are moving freely. If not, clear the obstruction away so that the arms may rotate freely and then rewash the load of dishes in the dishwasher.

  Spots that appear on the stainless steel door may be removed by wiping gently with a sponge sprinkled with a stainless steel cleaner. Do not use metal scouring pads to clean the stainless steel surfaces as these can scratch the surface and leave metal fragments that can rust.

- Door Gasket
  The door gasket should be cleaned on a regular basis to remove food particles that can gather from normal loading. If necessary, clean the door gasket using a damp cloth.

SERVICE and REPAIR

English

The Bosch dishwasher requires no special care other than the care and cleaning noted above. If you are having a problem with your dishwasher, before calling for service please refer to Table 3, SELF-HELP section. If service becomes necessary, contact your dealer, installer, or an authorized service center. Do not attempt to repair the appliance yourself. Any work performed by unauthorized personnel may VOID THE WARRANTY.

If you are having a problem with your BOSCH dishwasher and are not pleased with the service you have received:

- First, please contact your installer or the Bosch Authorized Service Contractor in your area and explain to them why you are not satisfied. This will usually correct the problem.
- If after working with your installer or service person the problem still has not been resolved to your satisfaction, please let us know by either writing to us at:

BSH Home Appliances Corp.
5551 McFadden Avenue
Huntington Beach, CA 92649
or,
calling us at:

1-800/944-2904.
(Staffed, 8:30 AM - 4:30 PM CST.)

Please be sure to include, if writing; or have available if calling, the following information:

- Model Number
- Serial Number
- Date of Original Purchase
- Date Problem Originated
- Explanation of Problem
- Daytime Phone Number

You will find the model number and serial number information on the rating plate located on the door of the dishwasher. See Figure 1.



Figure 12.

THIS INFORMATION CAN ALSO BE FOUND ON YOUR INVOICE.

SELF-HELP

Dishwashers may exhibit problems that are unrelated to a malfunction of the dishwasher itself. The following table may serve to answer your question about a problem you are having without having to call a serviceman.

PROBLEM	POSSIBLE CAUSE
Dishes do not dry	Rinse-aid dispenser is empty. Fill rinse-aid dispenser.
Indicator light(s) do not come on	A fuse may have blown or a circuit breaker tripped. Replace fuse or reset circuit breaker at your fuse box/breaker box.
Dishwasher does not start	Door of dishwasher not properly closed. Close dishwasher making sure that door latches.
Dishwasher runs a long time	If the dishwasher completes the cycle, but the run time seem exceptionally long it is probably due to cold incoming water. To avoid this problem it is recommended that before starting the dishwasher: open the hot water faucet at the sink nearest the dishwasher and run the water until the water is hot. Then turn off the water and start the dishwasher.
Machine cycle does not advance to rinse	Water line is closed or inlet filter is blocked. Open water valve and/or check inlet filter.
Water not pumped from dishwasher	Kink in drain hose. Filter clogged. Kitchen sink clogged. Air gap (type installed at sink) clogged. Check drain hose and fine and coarse filters (see section titled CARE and CLEANING). Check kitchen sink to make sure it is draining well. If problem is kitchen sink not draining you may need a plumber rather than a serviceman for the dishwasher.
Detergent dispenser lid will not close	A program was not completely finished.
Lower spray arm does not rotate freely	Remove lower spray arm and clean arm and spray arm mounts.
White deposits left on dishes	Too little rinse-aid.
Streaks on glassware	Too much rinse-aid used.
Rattling noises	Utensils not properly arranged.
Suds in dishwasher	Incorrect type of detergent used. Use only automatic dishwasher detergents.
Unsatisfactory washing result	• Incorrect amount of detergent or rinse agent. • Utensils incorrectly arranged or rack overloaded. • Wash arm rotation blocked by utensils. • Filters not properly fitted into position. • Clogged nozzles in wash arm(s) • Unsuitable program selected.

TABLE 3.

English

STATEMENT OF WARRANTIES
BOSCH DISHWASHER

The warranties provided by the BSH Home Appliances Corp. ("Bosch") in this Statement of Warranties apply only to Bosch Dishwashers sold to the first using purchaser by Bosch or its authorized dealers, retailers or service centers in the United States or Canada. The Warranties provided herein are not transferable.

LENGTH OF WARRANTY	SCOPE OF WARRANTY
1 Year Full Limited Warranty From Date of Installation*	Bosch will repair or replace any component part that proves defective under conditions of normal home use free of charge, labor and shipping costs included. Repair service must be performed by an Authorized Bosch Service Center (excludes: cosmetic items).
2 Year Limited Warranty From Date of Installation*	Bosch will provide replacement parts free of charge for any component part that proves defective under conditions of normal home use, labor charges excluded (excludes: cosmetic items).
5 Year Limited Warranty on Electronics From Date of Installation*	Bosch will repair or replace any microprocessor or printed circuit boards that prove defective under normal use during the second through fifth year from the date of original purchase, labor charges excluded.
5 Year Limited Warranty From Date of Installation*	Bosch will replace the upper or lower dish rack (excluding rack components) free of charge, if the rack proves defective in materials or workmanship under conditions of normal home use, labor charges excluded.
Lifetime Limited Warranty against Stainless Steel Rust Through From Date of Installation*	Bosch will replace your dishwasher with the same model or a current model that is equivalent or better in functionality if the inner liner should rust through under conditions of normal home use, labor charges excluded. Bosch will replace the stainless steel door of any dishwasher if the door should rust through under conditions of normal home use, labor charges excluded.

** Date of installation shall refer to the earlier of the date the dishwasher is installed or ten business days after the delivery date.*

Exclusions.

This warranty does not cover service calls or repairs to correct the installation of the dishwasher, to provide instructions on the use of your dishwasher, to replace house fuses or correct plumbing or the electric wiring in your home or to repair any dishwasher that's use was in a manner other than what is normal and customary for home use. In addition, the warranties provided in this Statement exclude any defects or damage arising from accident, alteration, misuse, abuse, improper installation, unauthorized service work, external forces beyond Bosch's control, such as fire, flood, and other acts of God, or installation not in accordance with local electrical and plumbing codes. Labor charges incurred in the repair or replacement of any dishwasher after the one year from date of installation shall not be covered by this warranty. Any and all replaced and/or repaired parts shall assume the identity of the original for purposes of the applicable warranty period.

TO THE EXTENT PERMITTED BY LAW, THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. BOSCH DOES NOT ASSUME ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

TO OBTAIN WARRANTY SERVICE, CONTACT THE NEAREST BOSCH AUTHORIZED SERVICE CENTER OR CALL 1 - 800 / 944 - 2904, OR WRITE BSH HOME APPLIANCES CORP. DIRECTLY AT: BSH HOME APPLIANCES CORP., 5551 McFADDEN AVENUE, HUNTINGTON BEACH, CA 92649. BE SURE TO PROVIDE YOUR DISHWASHER'S MODEL, SERIAL NUMBER, PURCHASE DATE AND THE SELLER'S NAME AND ADDRESS.[1]

NOTES

NOTES